



MSL56-18RC

MUSIC STAND LIGHT USER MANUAL

Customer Services:

Tel: +44 (0) 1892 280 107

Email: sales@tigermusic.co.uk

Website: www.tigermusic.co.uk

Address

Tiger Music Distribution Ltd,
Unit 9, Dana Estate
Transfesa Road,
Paddock Wood, Kent,
TN12 6UT
UK
Made in China

EU Authorised Representative Address

Manufacturer: Tiger Music Distribution Ltd
Comply Express Unipessoal Lda
StartUp Madeira EV141
Campus da Penteada
Funchal 9020-105
Portugal



PLEASE READ AND RETAIN ALL PACKAGING FOR FUTURE REFERENCE

- Keep out of reach of small children; contains small parts.
- Use indoors only; avoid moisture and extreme temperatures.
- Do not operate with wet hands or near water.
- Never cover LED heads while in use to prevent overheating.
- Do not disassemble, modify, or attempt repairs yourself. No user serviceable parts.
- Do not puncture, crush, or attempt to open the battery casing.
- Inspect for cracks or loose parts before each use; do not use if damaged.
- Charge only using the supplied USB-C cable and a USB wall adapter.
- Do not use fast-charging adapters.
- Avoid charging near flammable materials or in direct sunlight.
- Do not leave the device connected to the charger for extended periods when not in use.
- Do not bend or damage the USB-C connector; replace the cable if frayed or broken.
- If the product or cable shows signs of overheating, stop charging immediately.
- Do not expose the product or cable to fire, heat, or liquids.
- Avoid leaving the light switched on unattended for long periods.
- Clean with a dry or slightly damp cloth. Avoid using cleaning chemicals.

OPERATING INSTRUCTIONS

1. Attaching the Light

Open the clip and attach it securely to a music stand or table up to 3.5cm thick.

2. Positioning the Heads

Adjust the flexible goosenecks to the desired angle.

3. Powering On/Off

- Tap the touch-sensitive button located on the lamp head to turn the light on or off.

4. Adjusting Brightness

- Press and hold the touch button to gradually adjust brightness.
- Release when you reach the desired level.
- Tap again to turn off or repeat the hold to dim in the opposite direction.

5. Changing Colour Modes

- Tap the mode selector to switch between Warm White and Cool White lighting.

USB Operation and Charging - Input (5V = 1A)

- Connect supplied USB-C cable to the USB port. Plug the cable into a USB power source.
- For optimal performance, fully charge the light before use. If the battery is low, the light may appear dim or not function properly when operated while charging.
- The charging indicator LED on the unit will be red while charging and will turn green to indicate full charge.



UK: If you encounter any issues with your product, we're here to help. To access the product manual and recycling information in your preferred language, or contact us directly scan this QR code or visit: www.tigermusic.co.uk/productinformation

DE: Wenn Sie Probleme mit Ihrem Produkt haben, sind wir hier, um zu helfen. Um auf das Produktmanual und Informationen zum Recycling in Ihrer bevorzugten Sprache zuzugreifen oder uns direkt zu kontaktieren, scannen Sie diesen QR-Code oder besuchen Sie: www.tigermusic.co.uk/productinformation

ES: Si encuentras algún problema con tu producto, estamos aquí para ayudarte. Para acceder al manual del producto e información sobre reciclaje en tu idioma preferido, o contactarnos directamente, escanea este código QR o visita: www.tigermusic.co.uk/productinformation

FR: Si vous rencontrez des problèmes avec votre produit, nous sommes là pour vous aider. Pour accéder au manuel du produit et aux informations sur le recyclage dans votre langue préférée, ou nous contacter directement, scannez ce code QR ou visitez : www.tigermusic.co.uk/productinformation

IT: Se incontri problemi con il tuo prodotto, siamo qui per aiutarti. Per accedere al manuale del prodotto e alle informazioni sul riciclo nella tua lingua preferita, o contattarci direttamente, scannerizza questo codice QR o visita: www.tigermusic.co.uk/productinformation

NL: Als u problemen ondervindt met uw product, staan wij voor u klaar om te helpen. Om toegang te krijgen tot de producthandleiding en recyclinginformatie in uw voorkeurs taal, of rechtstreeks contact met ons op te nemen, scan deze QR-code of bezoek: www.tigermusic.co.uk/productinformation

PL: Jeśli napotkasz jakiegokolwiek problemy z produktem, jesteśmy tutaj, aby pomóc. Aby uzyskać dostęp do instrukcji obsługi produktu i informacji o recyklingu w wybranym przez Ciebie języku, lub skontaktować się z nami bezpośrednio, zeskanuj ten kod QR lub odwiedź : www.tigermusic.co.uk/productinformation

SE: Om du stöter på några problem med din produkt är vi här för att hjälpa till. För att få tillgång till produktmanualen och återvinningsinformationen på ditt föredragna språk, eller kontakta oss direkt, skanna den här QR-koden eller besök: www.tigermusic.co.uk/productinformation